


---

# LANDROLLER



## LANDROLLER | 64 | 80

143629 v1.0

**DEGELMAN INDUSTRIES LP**  
BOX 830-272 INDUSTRIAL DRIVE,  
REGINA, SK, CANADA, S4P 3B1  
FAX 306.543.2140 PH 306.543.4447  
1.800.667.3545 DEGELMAN.COM

**FIVE-PLEX**  
**LANDROLLER | 64 | 80**  
SN: LR9530 and up



# QUICK-START GUIDE\*

## for FIVE-PLEX LANDROLLER

\* Refer to operators manual for complete safety and operation info.



**Degelman**

## A Connect Hydraulics

- 1 WHEEL CIRCUIT.....Wheel Cylinders
- 2 FRONT HITCH CIRCUIT.....Front Hitch Cylinder
- 3 SPREADER ARM CIRCUIT....Spreader Arm Cylinders

## B Backing Into Field Position

- 1) Drive landroller onto level ground, straight behind the tractor.


- Ensure there is plenty of room behind and to the sides of the landroller for backing into field position.

- 2) Remove all five red transport bars. Place the transport bars onto the storage brackets provided and secure with lock-pin.

(4 on wheel cylinders, and 1 on front hitch cylinder).

**Note:** You may need to activate (extend) the hydraulic cylinders slightly to allow removal of the cylinder transport bars.

- 3) Slowly back-up while activating the spreader arm hydraulics until the wings are mostly open or approximately 15°-30° degrees from being in line.




- Retract this circuit upon completion -

- 4) Fully raise the transport wheels to lower the rollers to the ground.

- 5) Continue backing up until both Swing-Arms lock into the latches.


- 6) **IMPORTANT:** Set the tractor hydraulic remote that activates the hitch pole cylinder into "float" position. This will allow the hitch pole to contour more effectively and prevent strain or possible damage to the machine.

- 7) The Landroller is now in field ready position.




# C Moving Into Transport Position


1) Drive onto level ground. Ensure that the hitch pole cylinder circuit is out of "float" position.




2) Fully extend the transport wheel cylinders to raise the rollers off ground and activate the hitch pole cylinder to allow installation of all five (5) red transport bars.  
(4 located on wheel cylinders, and 1 on front hitch cylinder).



3) Activate these circuits again to allow cylinders to rest on the red transport bars.



4) Slowly drive forward and wings should fall-back in line behind the center frame.



5) Switch on safety lights and check operation.

6) The Landroller is now in transport position.



## Maintenance

(Check Machine Daily)

- Check for missing, worn or damaged parts.
- Working points & pins
- Hydraulic Connections & Hoses
- Hubs & Spindles

\* Refer to operators manual for complete safety and operation info.

# LANDROLLER | 64 | 80

\* Reference Sheet Quick-Start Guide

## OPERATORS SECTION - TABLE OF CONTENTS

<b>Introduction</b>	<b>1</b>
<b>Safety</b>	<b>2</b>
<b>Operation</b>	<b>4</b>
Pre-Operation Checklist	5
Hook-Up / Floating Hitch System	6
Transport to Field Position	7
Field to Transport Position	8
<b>Service &amp; Maintenance</b>	
Maintenance Checklist and Specifications	10
Repair - Hydraulic Cylinder Repair	14
Repair - Wheel Hub	15
Troubleshooting	16
Decal Location Overview	17

## PARTS SECTION - TABLE OF CONTENTS

### **Part Assemblies & Components**

Hitch Frame Components	19
Center Frame Components	20
Inner Wing Frame Components	22
Outer Wing Frame Components	23
Hub & Spindle Components	24

### **Hydraulic Routing**

Hydraulic Cylinders	25
Hydraulic Hose Holder Locations	26
Hydraulic Routing - Wheels Cylinders	27
Hydraulic Routing - Front Hitch Cylinder	28
Hydraulic Routing - Spreader Arm Cylinders	29
Electrical Layout & Light Components	30


<b>Warranty</b>	<b>31</b>
-----------------	-----------



## Introduction

---

# LANDROLLER | 64 | 80



**CONGRATULATIONS** on your choice of a Degelman Landroller to complement your farming operation. It has been designed and manufactured to meet the needs of a discerning agricultural market for increasing yields for high quality pulse crops and preparing the perfect bed for haying, grasses and silage. Degelman rollers provide a smooth and level surface for faster, easier harvest operations and better seed-to-soil contact. Use this manual as your first source of information about this machine.

Safe, efficient and trouble free operation of your Degelman Landroller requires that you and anyone else who will be operating or maintaining it, read and understand the Safety, Operation, Maintenance and Troubleshooting information contained within this manual.

Keep this manual handy for frequent reference and to pass on to new operators or owners. Call your Degelman Dealer if you need assistance, information, or additional copies of the manual.

**OPERATOR ORIENTATION** - The directions left, right, front and rear, as mentioned throughout the manual, are as seen from the tractor drivers' seat and facing in the direction of travel.

## Why is SAFETY important to YOU?

### 3 BIG Reasons:

- Accidents Can Disable and Kill
- Accidents Are Costly
- Accidents Can Be Avoided



### SAFETY ALERT SYMBOL

---

The **Safety Alert Symbol** identifies important safety messages applied to the Landroller and in this manual. When you see this symbol, be alert to the possibility of **injury or death**. Follow the instructions provided on the safety messages.

The **Safety Alert Symbol** means:  
**ATTENTION!**  
**BECOME ALERT!**  
**YOUR SAFETY IS INVOLVED!**

### SIGNAL WORDS

---

Note the use of the Signal Words: **DANGER**, **WARNING**, and **CAUTION** with the safety messages. The appropriate Signal Word has been selected using the following guidelines:

**DANGER**

**DANGER:** Indicates an imminently hazardous situation that, if not avoided, **WILL** result in death or serious injury if proper precautions are not taken.

**WARNING**

**WARNING:** Indicates a potentially hazardous situation that, if not avoided, **COULD** result in death or serious injury if proper precautions are not taken.

**CAUTION**

**CAUTION:** Indicates a potentially hazardous situation that, if not avoided, **MAY** result in minor or moderate injury if proper practices are not taken, or, serves as a reminder to follow appropriate safety practices.

# Safety

---

## SAFETY

---

**YOU** are responsible for the safe operation and maintenance of your Degelman Landroller. **YOU** must ensure that you and anyone else who is going to operate, maintain or work around the Landroller be familiar with the operating and maintenance procedures and related **SAFETY** information contained in this manual. This manual will take you step-by-step through your working day and alerts you to all good safety practices that should be adhered to while operating this equipment.

Remember, **YOU** are the key to safety. Good safety practices not only protect you but also the people around you. Make these practices a working part of your safety program. Be certain that **EVERYONE** operating this equipment is familiar with the recommended operating and maintenance procedures and follows all the safety precautions. Most accidents can be prevented. Do not risk injury or death by ignoring good safety practices.

- Landroller owners must give operating instructions to operators or employees before allowing them to operate the Landroller, and at least annually thereafter per OSHA regulation 1928.51.
- The most important safety device on this equipment is a SAFE operator. It is the operator's responsibility to read and understand ALL Safety and Operating instructions in the manual and to follow these. All accidents can be avoided.
- A person who has not read and understood all operating and safety instructions is not qualified to operate the machine. An untrained operator exposes himself and bystanders to possible serious injury or death.
- Do not modify the equipment in any way. Unauthorized modification may impair the function and/or safety and could affect the life of the equipment.
- Think SAFETY! Work SAFELY!

## GENERAL SAFETY

---

1. Read and understand the Operator's Manual and all safety signs before operating, maintaining or adjusting the Landroller.  

2. Install and properly secure all shields and guards before operating. Use hitch pin with a mechanical locking device.
3. Have a first-aid kit available for use should the need arise and know how to use it.  

4. Have a fire extinguisher available for use should the need arise and know how to use it.  

5. Wear appropriate protective gear. This list includes but is not limited to:
  - A hard hat
  - Protective shoes with slip resistant soles
  - Protective glasses or goggles
  - Heavy gloves
  - Wet weather gear
  - Hearing protection
  - Respirator or filter mask  

6. Clear the area of people, especially small children, and remove foreign objects from the machine before starting and operating.
7. Do not allow riders.
8. Stop tractor engine, set park brake, remove ignition key and wait for all moving parts to stop before servicing, adjusting, repairing or unplugging.
9. Review safety related items with all operators annually.


# Operation

## TO THE NEW OPERATOR OR OWNER

The Degelman Landroller is designed to provide a smooth and level surface.

It is the responsibility of the owner or operator to read this manual carefully to learn how to operate the machine safely. Safety is everyone's business. By following safe operating practices, a safe environment is provided for the operator and bystanders.


By following the operating instructions in conjunction with a good maintenance program your machine will provide many years of trouble-free service.



## OPERATING SAFETY

1. Read and understand the Operator's Manual and all safety signs before using.
2. Stop tractor engine, set park brake, remove ignition key and wait for all moving parts to stop before servicing, adjusting, repairing or unplugging.
3. Keep hands, feet, hair and clothing away from all moving and/or rotating parts.
4. Do not allow riders on the Landroller tractor during operation or transporting.
5. Keep all shields and guards in place when operating.
6. Clear the area of all bystanders, especially children, before starting.
7. Do not operate machine on overly steep side hills or slopes.
8. Be careful when working around or maintaining a high-pressure hydraulic system. Ensure all components are tight and in good repair before starting.
9. Clean all reflectors, lights and the SMV sign before transporting on a highway or public road. Be sure to check with local highway authorities and comply with their lighting requirements.

## Transport Position



# Operation

---

## BREAK-IN

---

Although there are no operational restrictions on the Landroller when it is new, there are some checks that should be done when using the machine for the first time, follow this procedure:

**⚠️ IMPORTANT:** *It is important to follow the Break-In procedures especially those listed in the "Before using" section below to avoid damage:*

**A. Before using:**

1. Read Safety Info. & Operator's Manual.
2. Complete steps in "Pre-Operation Checklist".
3. Lubricate all grease points.

**(Note:** Do **NOT** grease the **spherical bearings** on the roller ends even though they may have grease fittings. They come pre-lubricated and sealed from the factory)

4. Check all bolt tightness.
5. Check tires. Inflate to:  
Front Tires: 12.5L x 15-12 PLY **90 PSI (620 kPa)**  
Rear Tires: 385/65R x 22.5 **90 PSI (620 kPa)**

**B. After operating for 2 hours:**

1. Check all hardware. Tighten as required.
2. Check all hydraulic system connections. Tighten if any are leaking.

## PRE-OPERATION CHECKLIST

---

It is important for both personal safety and maintaining good operational condition of the machine that the pre-operational checklist be followed.

**Before operating the machine and each time thereafter, the following areas should be checked off:** 

1. Lubricate the machine per the schedule outlined in the "Maintenance Section".
2. Use only a tractor with adequate power to pull the Landroller under ordinary operating conditions.  
**Minimum: 250 HP (186 KW)**
3. Ensure that the machine is properly attached to the tractor using a drawbar pin with provisions for a mechanical retainer. Make sure that a retainer such as a Klik pin is installed.

**NOTE:** *It is important to pin the draw bar in the central location only.*

4. Before using, inflate tires to:  
Front Tires: 12.5L x 15-12 PLY **90 PSI (620 kPa)**  
Rear Tires: 385/65R x 22.5 **90 PSI (620 kPa)**
5. Ensure that a safety chain is installed on the hitch.
6. Check oil level in the tractor hydraulic reservoir.  
Top up as required.
7. Inspect all hydraulic lines, hoses, fittings and couplers for tightness. Tighten if there are leaks. Use a clean cloth to wipe any accumulated dirt from the couplers before connecting to the tractor's hydraulic system.

# Operation

---

## HOOK-UP / UNHOOKING

---

The Landroller should always be parked on a level, dry area that is free of debris and foreign objects. Follow this procedure to hook-up:

1. Clear the area of bystanders and remove foreign objects from the machine and working area.
2. Make sure there is enough room to back the tractor up to the trailer hitch.
3. Start the tractor and slowly back it up to the hitch point.
4. Stop the tractor engine, place all controls in neutral, set park brake and remove ignition key before dismounting.
5. Use the jack to raise or lower the hitch to align with the drawbar.
6. Install a drawbar pin with provisions for a mechanical retainer such as a KLIK pin. Install the retainer.
7. Install a safety chain between the tractor and the hitch.
8. Connect the hydraulics. To connect, proceed as follows:
  - Use a clean cloth or paper towel to clean the couplers on the ends of the hoses. Also clean the area around the couplers on the tractor. Remove the plastic plugs from the couplers and insert the male ends.
  - Be sure to match the pressure and return line to one valve bank.
9. Connect lights (electrical socket plug) to tractor.
10. Raise the hitch jack and rotate it 90° to place in its stowed position.
11. When unhooking from the tractor, reverse the above procedure.

## FLOATING HITCH SYSTEM

---

### FRONT HYDRAULIC CYLINDER CIRCUIT MUST BE SET TO FLOAT DURING FIELD OPERATION

The floating hitch system provides the Landroller with more flexibility while in the field position. The hydraulic cylinder must be set on "float" to allow the roller to move freely over the terrain without being restricted by the hitch. Failure to set the cylinder to float may cause serious damage to the machine.

**⚠️ IMPORTANT:** *It is extremely important that the front hitch cylinder circuit be set in the "float" position when operating the Landroller for proper operation and to prevent damage to the machine. For more information on setting a hydraulic circuit in "float" please refer to your tractor's operational manual.*

**IMPORTANT**  
**HITCH CYLINDER CIRCUIT  
MUST BE IN FLOAT  
POSITION WHEN OPERATING  
IN FIELD POSITION**

**Le Circuit Hydraulique de la  
Barre de tire devrait etre en  
position Flottante lors des  
operations au champs.**

143280


# Operation

## TRANSPORT TO FIELD POSITION


1. Drive the Landroller onto level ground so it is straight behind the tractor.
2. Activate the appropriate hydraulics to allow removal of all five (5) red transport bars. Place the transport bars onto the storage brackets provided and secure with lock-pin.
3. Slowly back-up the Landroller while at the same time activating the hydraulics which operate the wing spreader arms until the wings are approximately 15-30 Degrees from being in line with the center frame.

*The spreader arms will assist (if necessary) to spread the wings apart to a limited angle. Retract this circuit upon completion.*

(Note: the relief valve plumbed into this circuit will prevent accidental damage should the operator forget to retract these arms.)



4. Fully retract the transport wheels to lower rollers to ground.
5. Continue backing up until the Swing-Arms lock into latches.
6. **⚠️ IMPORTANT:** Set the tractor hydraulic remote that activates the hitch pole cylinder into "float" position which will allow the hitch pole to contour more effectively and prevent strain and possible damage to the machine.
7. The roller is now in field ready position.




# Operation

---

## FIELD POSITION TO TRANSPORT

---

1. Drive onto level ground. Ensure that the hitch pole cylinder circuit is out of "float" position.
2. Fully extend the transport wheel cylinders to raise the rollers off ground and activate the hitch pole cylinder to allow installation of all five (5) red transport bars.
3. Activate these circuits again to allow the cylinder's to rest on the red transport bars.
4. Slowly drive forward and wings should fall-back in line behind the center frame.
5. Switch on safety lights and check operation.
6. The machine is now in transport position.



# Operation

---

## TRANSPORT SAFETY

---

1. Read and understand ALL the information in the Operator's Manual regarding procedures and SAFETY when operating the Landroller in the field/yard or on the road.
2. Check with local authorities regarding machine transport on public roads. Obey all applicable laws and regulations.
3. Always travel at a safe speed. Use caution when making corners or meeting traffic.
4. Make sure the SMV (Slow Moving Vehicle) emblem and all the lights and reflectors that are required by the local highway and transport authorities are in place, are clean and can be seen clearly by all overtaking and oncoming traffic.
5. Keep to the right and yield the right-of-way to allow faster traffic to pass. Drive on the road shoulder, if permitted by law.
6. Always use hazard warning flashers on tractor when transporting unless prohibited by law.
7. Always use a pin with provisions for a mechanical retainer and a safety chain when attaching to a tractor or towing vehicle.

## TRANSPORTING

---

*Use the following guidelines while transporting the Landroller:*

1. Use a safety chain.
2. Ensure all transport locks are securely in place.
3. Be sure hazard lights are flashing and SMV decal is visible.
4. MAXIMUM RECOMMENDED TRANSPORT SPEED: 30 km/h or 19 mph. (Road Conditions. Field speeds may be lower.)

**⚠️ IMPORTANT: UNDER NO CIRCUMSTANCES SHOULD THERE EVER BE RIDERS WHILE THE LANDROLLER IS IN TRANSPORT.**



# Service & Maintenance

---

## MAINTENANCE SAFETY

---

1. Review the Operator's Manual and all safety items before working with, maintaining or operating the Landroller.
2. Stop the tractor engine, set park brake, remove ignition key and wait for all moving parts to stop before servicing, adjusting, repairing or unplugging.
3. Keep hands, feet, clothing and hair away from all moving and/or rotating parts.
4. Clear the area of bystanders, especially children, when carrying out any maintenance and repairs or making any adjustments.
5. Place safety stands or large blocks under the frame before removing tires or working beneath the machine.
6. Be careful when working around or maintaining a high-pressure hydraulic system. Wear proper eye and hand protection when searching for a high pressure hydraulic leak. Use a piece of wood or cardboard as a backstop when searching for a pin hole leak in a hose or a fitting.
7. Always relieve pressure before disconnecting or working on hydraulic system.

## MAINTENANCE CHECKLIST

---

Use the Maintenance Checklist provided for regular service intervals and keep a record of all scheduled maintenance:

*(Note: Do NOT grease the spherical bearings)*

### Maintenance Check - 10 Hours

- Hydraulic fluid leaks
- Damaged hoses
- Check tire pressure:  
Front: 12.5L x 15 - 90 PSI (620 kPa)  
Rear Tires: 385/65R - 90 PSI (620 kPa)

### Grease Points - 25 Hours

- Front Hitch Frame Pins
- Swing-Arm Holders
- Cylinder Pins
- Spreader-Arm Pins
- Cast Bearings
- Cross Joint Pins
- Wing Joint Pins
- Transport Wheel Arm Holders
- Transport Wheel Pins
- Hubs & Spindles

### Grease Points - 50 Hours

- Working points & pins
- Safety signs clean

### Annually

- Bolt tightness
- Wheel bearings
- Latch mechanism
- Cable assembly

# Service & Maintenance

---

## SERVICE

---

### GREASING

Grease: Use an SAE multipurpose grease with extreme pressure (EP) performance. Also acceptable is an SAE multipurpose lithium.

1. Use only a hand-held grease gun for all greasing.
2. Wipe grease fitting with a clean cloth before greasing, to avoid injecting dirt.
3. Replace and repair broken fittings immediately.
4. If fittings will not take grease, remove and clean thoroughly. Also clean lubricant passageway. Replace fitting if necessary.
5. Inject grease until you see grease being expelled from the bearing or bushing areas.

## TIRE SAFETY

---

1. Failure to follow proper procedures when mounting a tire on a wheel or rim can produce a blow out which may result in serious injury or death.
2. Do not attempt to mount a tire unless you have the proper equipment and experience to do the job.
3. Have a qualified tire dealer or repair serviceman perform required tire maintenance.

## STORAGE

---

The Landroller should be carefully prepared for storage to ensure that all dirt, mud, debris and moisture has been removed.

*Follow this procedure when preparing to store:*

1. Wash the entire machine thoroughly using a water hose or pressure washer to remove all dirt, mud, debris or residue.
2. Inspect all parts to see if anything has become entangled in them. Remove the entangled material.
3. Lubricate all grease fittings to remove any moisture in the bearings.
4. Inspect all hydraulic hoses, fittings, lines and couplers. Tighten any loose fittings. Replace any hose that is badly cut, nicked or abraded or is separating from the crimped end of the fitting.
5. Touch up all paint nicks and scratches to prevent rusting.
6. Oil the exposed rams on the hydraulic cylinder to prevent rusting.
7. Select an area that is dry, level and free of debris.

# Service & Maintenance

## HARDWARE SPECIFICATIONS

**Note:** Unless stated otherwise, hardware is typically:  
Hex, Plated GR5 UNC or P8.8 (metric)

## TORQUE SPECIFICATIONS

### Checking Bolt Torque

The tables below give correct torque values for various bolts and capscrews. Tighten all bolts to the torques specified in chart unless otherwise noted. Check the tightness of bolts periodically, using these bolt torque charts as a guide. Replace hardware with the same strength (Grade/Class) bolt.



TORQUE

### IMPERIAL TORQUE SPECIFICATIONS

(Coarse Thread - based on "Zinc Plated" values)



Size	Grade 5	Grade 8
1/4"	7 (10)	10 (14)
5/16"	15 (20)	20 (28)
3/8"	25 (35)	35 (50)
7/16"	40 (55)	60 (80)
1/2"	65 (90)	90 (120)
9/16"	90 (125)	130 (175)
5/8"	130 (175)	180 (245)
3/4"	230 (310)	320 (435)
7/8"	365 (495)	515 (700)
1"	550 (745)	770 (1050)
1-1/8"	675 (915)	1095 (1485)
1-1/4"	950 (1290)	1545 (2095)
1-3/8"	1250 (1695)	2025 (2745)
1-1/2"	1650 (2245)	2690 (3645)

### METRIC TORQUE SPECIFICATIONS

(Coarse Thread - based on "Zinc Plated" values)



Size	Class 8.8	Class 10.9
M6	7 (10)	10 (14)
M8	16 (22)	23 (31)
M10	30 (42)	45 (60)
M12	55 (75)	80 (108)
M14	90 (120)	125 (170)
M16	135 (185)	195 (265)
M18	190 (255)	270 (365)
M20	265 (360)	380 (515)
M22	365 (495)	520 (705)
M24	460 (625)	660 (895)
M27	675 (915)	970 (1315)
M30	915 (1240)	1310 (1780)
M33	1250 (1695)	1785 (2420)
M36	1600 (2175)	2290 (3110)

## HYDRAULIC SAFETY



- Make sure that all components in the hydraulic system are kept in good condition and are clean.
- Replace any worn, cut, abraded, flattened or crimped hoses and metal lines.
- Do not attempt any makeshift repairs to the hydraulic lines, fittings or hoses by using tape, clamps or cements. The hydraulic system operates under extremely high-pressure. Such repairs will fail suddenly and create a hazardous and unsafe condition.
- Wear proper hand and eye protection when searching for a high-pressure hydraulic leak. Use a piece of wood or cardboard as a backstop instead of hands to isolate and identify a leak.
- If injured by a concentrated high-pressure stream of hydraulic fluid, seek medical attention immediately. Serious infection or toxic reaction can develop from hydraulic fluid piercing the skin surface.
- Before applying pressure to the system, make sure all components are tight and that lines, hoses and couplings are not damaged.



## HYDRAULIC HOSE SPECIFICATIONS



**Note:** Unless otherwise stated, Hydraulic Hoses are either 3/8 or 1/2 with 3/4 JIC female swivel ends.

## HYDRAULIC HOSE INSTALLATION TIPS



The following tips are to help you identify some possible problem areas in the installation of hydraulic hoses.

1. Installation should be completed in a clean environment clear of dust and contaminants. Hoses and fittings should be capped if not installed.
2. Ensure hoses are not twisted during installation as this may weaken the hose. Also, the pressure in a twisted hose may loosen fittings or connections.
3. Allow sufficient bend radius in hoses when installing to prevent lines from collapsing and flow becoming restricted.
4. When installing hoses in an area of movement or flexing, allow enough free length for motion and to ensure fitting connections are not stressed.
5. Ensure hoses are properly clamped and secured in position after routing is complete to provide a cleaner installation and prevent possible damage or hazards.

# Service & Maintenance

## HYDRAULIC FITTING INSTALLATION



The following info is to help you identify and properly install some of our standard hydraulic fittings.

### SAE (JIC) 37° Flare

JIC fittings - Metal-to-metal sealing type fittings featuring a 37° flare (angle of sealing surface) and straight UNF (Unified National Fine) Threads.



(Lubricated Values)	<b>Dash</b>	<b>Thread Size</b>	<b>Torque - lb.ft (N.m)</b>
	-4	7/16 - 20	9-12 (12-16)
	-6	9/16 - 18	14-20 (19-27)
	-8	3/4 - 16	27-39 (37-53)
	-10	7/8 - 14	36-63 (50-85)
	-12	1-1/16 - 12	65-88 (90-119)

### Tightening JIC 37° Flare Type Fittings

1. Check flare and flare seat for defects that might cause leakage.
2. Align fittings before tightening. Lubricate connections & hand tighten swivel nut until snug.
3. Using two wrenches, torque to values shown in table.

**Alternate Installation Method**

3. Using two wrenches. Place one wrench on the fixed connector body at a clock position of **6 o'clock**.
4. Place the second wrench on the second connection as close to the **3 o'clock** position as possible.
5. Tighten by rotating the second connection firmly to at least the **4 o'clock** position, but no more than the **7 o'clock** position. Typically, the larger the fitting size the less rotation required.



### ORFS (O-Ring Face Seal)

ORFS fittings use an O-ring compression method to seal. This method offers a high level of sealing along with good vibration resistance. Male fittings include an O-ring located in a groove on the flat face. Female fittings feature a flat face and UNF straight threaded swivel nut.

The **Torque** method is recommended for ORFS installation.

<b>Dash</b>	<b>Thread Size</b>	<b>Torque - lb.ft (N.m)</b>
-4	9/16 - 18	18 (25)
-6	11/16 - 16	30 (40)
-8	13/16 - 16	40 (55)
-10	1 - 14	60 (80)
-12	1-3/16 - 12	85 (115)

### Tightening ORFS (O-Ring Face Seal) Fittings

1. Inspect components and ensure the O-Ring seal is undamaged and properly installed in the groove of the face seal. Replacing the O-Ring may be necessary.
2. Align, thread into place and hand tighten.
3. Tighten to proper torque from the table shown above.

**Note:** A **DASH** size refers to a diameter of a hose (*inside*) or of a tube (*outside*) measured in  $1/16"$  increments.

For example, a **Hose** specified as **dash 8** or **-8** would have an **inside** diameter of  $8/16"$  or  $1/2"$ .

Alternatively, a **Tube** specified as **dash 8** or **-8** would have an **outside** diameter of  $8/16"$  or  $1/2"$ .

### ORB (O-Ring Boss)


Male ORB fittings have straight UNF threads, a sealing face and an O-ring. The female fittings are generally found in the ports of machines and feature straight threads, a machined surface, and a chamfer to accept the O-ring. Sealing is achieved through the compression of the male O-ring against the chamfered sealing face of the female fitting.

(Lubricated Values)	<b>Dash</b>	<b>Thread Size</b>	<b>Torque - Non-Adjustable lb.ft (N.m)</b>	<b>Torque - Adjustable lb.ft (N.m)</b>
	-4	7/16 - 20	30 (40)	15 (20)
	-6	9/16 - 18	35 (46)	35 (46)
	-8	3/4 - 16	60 (80)	60 (80)
	-10	7/8 - 14	100 (135)	100 (135)
	-12	1-1/16 - 12	135 (185)	135 (185)

### Tightening ORB (O-Ring Boss) Fittings

#### Non-adjustable Port End Assembly

1. Inspect the components to ensure that male and female threads and sealing surfaces are free of nicks, burrs, scratches, or any foreign material.
2. Ensure O-Ring seal is properly installed and undamaged.
3. Lubricate threads and O-ring to help the O-ring slide past the port entrance corner and avoid damaging it.
4. Screw the fitting into position tighten to proper torque value from the table shown above.



#### Adjustable Port End Assembly

1. Inspect the components to ensure male & female threads and sealing surfaces are free of nicks, burrs, scratches, or any foreign material.
2. Ensure O-Ring seal is properly installed and undamaged.
3. Lubricate threads and O-ring to help the O-ring slide smoothly into the port and avoid damage.
4. Loosen back the lock nut as far as possible. Make sure back-up washer is not loose and is pushed up as far as possible.
5. Screw the fitting into port until the back-up washer or the retaining ring contacts face of the port. Light wrenching may be necessary. Over tightening may damage washer.
6. To align the end of the fitting to accept incoming tube or hose assembly, unscrew the fitting by the required amount, but not more than one full turn.
7. Using two wrenches, hold the fitting in desired position and tighten the locknut to the proper torque value from the table located above.
8. Inspect to ensure that O-ring is not pinched and that washer is seated flat on the face of the port.

# Service & Maintenance

## HYDRAULIC CYLINDER REPAIR

### PREPARATION

When cylinder repair is required, clean off unit, disconnect hoses and plug ports before removing cylinder.


When removed, open the cylinder ports and drain the cylinder's hydraulic fluid.

Examine the type of cylinder. Make sure you have the correct tools for the job.


*You may require the following tools:*

- Proper Seal Kit
- Allen Key Set
- Emery cloth
- Torque Wrench

### Threaded Head Cylinder (Monarch)




## CYLINDER ROD LOCKNUT TORQUE VALUES



LOCKNUT SIZE (PISTON)	TORQUE VALUE
3/8 - 24 UNF	25-30 lb.ft (35-42 N.m)
1/2 - 20 UNF	<b>40-60 lb.ft (55-80 N.m)</b>
5/8 - 18 UNF	95-105 lb.ft (130-140 N.m)
3/4 - 16 UNF	<b>175-225 lb.ft (240-305 N.m)</b>
7/8 - 14 UNF	200-275 lb.ft (270-370 N.m)
1 - 14 UNF	<b>300-380 lb.ft (405-515 N.m)</b>
1 1/8 - 12 UNF	400-500 lb.ft (540-675 N.m)
1 1/4 - 12 UNF	<b>500-600 lb.ft (675-810 N.m)</b>
1 1/2 - 12 UNF	700-800 lb.ft (950-1085 N.m)
1 3/4 - 12 UNF	<b>800-900 lb.ft (1085-1220 N.m)</b>

## REPAIRING A THREADED HEAD CYLINDER

### Set Screw Style



### DISASSEMBLY

1. Loosen Set Screw and turn off end cap.
2. Carefully remove piston/rod/gland assemblies.
3. Disassemble the piston from the rod assembly by removing lock nut.

**NOTE:** *DO NOT* clamp rod by chrome surface.

4. Slide off gland assembly & end cap.
5. Remove seals and inspect all parts for damage.
6. Install new seals and replace damaged parts with new components.

7. Inspect the inside of the cylinder barrel, piston, rod and other polished parts for burrs and scratches. Smooth areas as needed with an emery cloth.

### REASSEMBLY

1. Reinstall rod through end cap & gland assembly.
2. Secure piston to rod with lock nut. Torque lock nut to proper value (refer to chart for proper torque value).
3. Lube inside of barrel, piston seals, and gland seals with hydraulic oil.
4. With cylinder body held gently in a vise, insert piston, gland, end cap and rod combination using a slight rocking motion.
5. Apply Loctite anti-seize before installing cylinder end cap.
6. Torque cylinder end cap to 440 lb.ft (600 N.m).
7. Tighten Set Screw on end cap to 6 lb.ft (8 N.m).

# Service & Maintenance

## WHEEL HUB REPAIR


### DISASSEMBLY

1. Remove dust cap.
2. Remove cotter pin from nut.
3. Remove nut and washer.
4. Pull hub off spindle.
5. Dislodge the inner cone bearing and dust seal.
6. Inspect cups that are press fitted into hub for pits or corrosion and remove if necessary.
7. Inspect and replace defective parts with new ones.

### ASSEMBLY

1. If cups need replacing, be careful to install them gently and evenly into hub until they are fully seated.
2. Apply a thick wall of grease inside hub. Pack grease in cones.
3. Install inner cone and dust seal as illustrated.
4. Position hub onto spindle and fill surrounding cavity with grease.
5. Assemble outer cone, washer and nut.
6. Tighten nut while rotating hub until there is a slight drag.
7. Turn nut back approximately 1/2 turn to align cotter pin hole with notches on nut.
8. Install cotter pin and bend legs sideways over nut.
9. Fill dust cap half full of grease and gently tap into position.
10. Pump grease into hub through grease fitting until lubricant can be seen from dust seal.

### COMMON HUB & SPINDLE COMPONENTS




**IMPORTANT:** Be sure to block up unit securely before removing tires.


## WHEEL NUT & WHEEL BOLT TORQUE




### BOLT PATTERNS



5 BOLT PATTERN



6 BOLT PATTERN



8 BOLT PATTERN



10 BOLT PATTERN

### Wheel Nut/Bolt Torque

Size	lb.ft (N.m)
9/16	120-130 (165-175)
5/8	185-190 (250-260)
3/4	280-300 (380-405)

### Wheel Tightening Procedure

1. Install and **hand tighten** nuts/bolts.
2. Tighten to approx. **20% Torque** value using the **Bolt Star or CrissCross** patterns shown above.
3. Tighten to **Full Torque** value using the **Star or CrissCross** pattern.
4. If applicable, install **Rear Locknuts** using **Wheel Torque Values**.

## TIRE SPECIFICATIONS

Front Tires: 12.5L x 15 - 12 PLY 90 PSI (620 kPa)


Rear Tires: 385/65R x 22.5 90 PSI (620 kPa)

## REMOVE & REPLACE REAR WHEEL



### IMPORTANT:

Lower the rollers onto the ground and raise transport wheel arms off the ground (ensure the weight is no longer on the transport wheels).



2. Loosen bolts on spindle offset assembly and remove bottom two bolts.
3. Remove spindle offset assembly/wheel from transport arm.
4. Remove and replace tire as needed.
5. Torque the 5/8 wheel nuts to 185-190 ft.lbs.
6. Reverse the sequence when installing.
7. Check tire inflation. See "Tire Specifications".

# Troubleshooting



## GENERAL TROUBLESHOOTING

SYMPTOM	PROBLEM	SOLUTION
<b>Uneven ground contour, and more compaction on the center section of the Landroller.</b>	The center hitch cylinder is not in the float position.	Ensure that the operator has the center hitch cylinder in the float position on his tractor.
<b>When driving in the field position, the wings fall back.</b>	When putting the Landroller into field position it is not latching correctly.	Ensure the Landroller is on level ground when backing up to the latch mechanism, and that the swing-arms fully engage into the latches. The transport wheels <b>must</b> be fully up in order for the latches to fully engage. If problem still occurs, adjust the eye bolt on the cable for mechanism to latch tighter.
<b>One wing won't open up into field position.</b>	Uneven ground, faulty relief, swing arm tubes seized and also possible binding in the cross joint area.	Ensure on level ground. Try backing up a slight slope to help assist the wings to fold out. Unhook the swing arm tube, and move manually to make sure that the swing arm is not seized. If problem stays contact your local Degelman dealer.
<b>Landroller rollers won't turn.</b>	Material build-up around rollers. If it is only one roller that doesn't turn, it might be a faulty bearing.	Ensure that there is no material build-up around rollers.
<b>Excessive play or excessive binding in rockshaft area (center frame wheel assembly).</b>	Cast support blocks around rockshaft not correctly adjusted.	Lower the rollers to the ground and lift the transport wheels off the ground. Check if the play in the rockshaft area is excessive. If so, remove the cap of the casting blocks around the rockshaft, and remove shims until desired clearance is needed to take the play out. Note: Do not remove too many shims, and make it too tight. If in case of binding make sure you have adequate grease in the block itself. Make sure, it's not rusted from a long time of storage in one position.
<b>Lowering into field, and raising into transport uneven.</b>	Rear square tubes on rear wheel frame down to tires become restricted or seizing.	Lower the rollers to the ground undo one of the pins, and move manually by hand to free up the tubing. Caution: If seized and then forced by hydraulics, it could cause failure in the tube area.
<b>Can't remove rear transport wheel for repair.</b>	Not enough clearance between roller drum and wheel hub.	Follow the Tire Maintenance procedure in the Service and Maintenance section of the manual which involves removing the cylinder pins.

# Service & Maintenance


## SAFETY DECALS AND REFLECTORS

- 1 142383 - Decal, Caution - 1-6 Point Safety (1)
- 2 142422 - Decal, Danger - Stay Clear Crush (3)
- 3 143280 - Decal, Important - Float Hitch (1)
- 4 142387 - Decal, Important - Red Transport Lock (5)
- 5 142557 - Reflector, Amber - 2 x 9 (12)
- 6 142556 - Reflector, Red - 2 x 9 (4)
- 7 142650 - Reflector, Fluorescent - 2 x 9 (4)
- 8 143162 - Decal, Read Operator's Manual (1)
- 9 142008 - Decal, Degelman (5)
- 10 143625 - Decal, Landroller 64 (2)  
143626 - Decal, Landroller 80 (2)
- 11 143677 - Decal, Hose Location (1)
- 12 142135 - Sign, SMV (1)







# Hitch Frame Components




## Front Hitch Detail




## Hitch to Center Frame Connection Detail




# Center Frame Components





## Typical Drum Roller Bearing Detail



**IMPORTANT:** Setscrew has a MAX Torque of 30 lb-ft (41 N-m), do not over-torque the setscrew.




## Autofold Latch Component Overview




# Center Frame Components

## Spreader Arm Component Detail




## Rockshaft Component Detail




# Inner Wing Frame Components


## Inner Wing Frame Component Overview



## Truss Arm-Wing Connection




## Wing Connection Detail



# Outer Wing Frame Components


## Outer Wing Frame Component Overview



# Hubs & Spindles


## 131324 - Hub/Spindle Assembly (4)

Center Frame Wheels



## 131735 - Hub/Spindle Assembly (2)


Rear Transport Wheels



# Hydraulic Cylinders

## ROCKSHAFT / SPREADER ARM CYLINDERS

123092 - Cylinder - 3-1/2 x 16 x 1-1/2, Monarch




## REAR TRANSPORT WHEEL CYLINDERS


### Requires:

118930 - Pin, 1 x 2-13/16 (1)   
118924 - Flat Washer .59 ID x .9 OD (1)   
118796 - Shoulder Bolt, 1/2 GR8 UNC (1) 

**64'** - 123092 - Cylinder - 3-1/2 x 16 x 1-1/2, Monarch



**80'** - 123414 - Cylinder - 4 x 16 x 2, Monarch



## FRONT HITCH CYLINDER


123093 - Cylinder - 3-1/2 x 8 x 1-1/2, Monarch



### Requires:


118930 - Pin, 1 x 2-13/16 (2)   
118924 - Flat Washer .59 ID x .9 OD (2)   
118796 - Shoulder Bolt, 1/2 GR8 UNC (2) 

# Hydraulic Hose Holder Locations




**NOTE: 80' Model shown.  
The 64' Model has two less clamp locations in  
this area.**




## Double Stack Hose Clamp



## Single Hose Clamp




# Hydraulic Routing - Wheel Cylinders




# Hydraulic Routing - Front Hitch Cylinder

## Float Valve Detail






Replacement spring: 143062 - Compression Spring (1)










## Float Cam Installation:

- 1 - Lower Landroller down with wheels fully retracted.
- 2 - Mount float valve onto bracket with the spool fully retracted and then back it off  $1/16"$  (basically, bolt the valve onto the bracket slots loosely, slide the valve down the slot until the button is pushed in all the way then raise it back up about  $1/16"$ , hold and tighten bolts)
- 3 - Tighten Hardware.



# Hydraulic Routing - Spreader Arm Cylinders





# Electrical Wiring

## 4-WIRE ROUTING OVERVIEW


Wire Harness - 4 Wire, w/plugs (1)  
 244615 - Wire Harness, LR-64'  
 244616 - Wire Harness, LR-80'

129045 - Hose Tie, 1/8 x 8  
 Light Wiring Cable runs along side the hydraulic hoses and is secured in place with hose ties.

### AMBER LIGHTS / SIGN BRACKETS



### REAR DUAL LIGHTS & HARDWARE



## **2 Year** Limited Warranty - Agricultural Products

Degelman Industries LP ("Degelman") warrants to the original purchaser of any new Degelman equipment, purchased from an authorized Degelman dealer, that the equipment will be free from defects in material and workmanship for a period of two (2) years from the date of delivery, for non-commercial use (including farm, institutional, government, and municipality) and (1) year from the date of delivery for commercial use. The obligation of Degelman to the purchaser under this warranty is limited to the repair or replacement of defective parts in the first year and to the provision, but not the installation of replacement parts in the second year. Degelman reserves the right to inspect any equipment or parts which are claimed to have been defective in material or workmanship.

This warranty limits its replacement or repair coverage to what is consistent with the warranty of Degelman's suppliers of purchased components.

Replacement or repair parts installed in the equipment covered by this limited warranty are warranted for ninety (90) days from the date of delivery of such part or the expiration of the applicable new equipment warranty period, which ever occurs later. Warranted parts shall be provided at no cost to the user at an authorized Degelman dealer during regular working hours. Warranted replacement parts will either be replaced or rebuilt at Degelman's discretion.

### ***Disclaimer of implied warranties & consequential damages***

This warranty shall not be interpreted to render Degelman Industries LP liable for injury, death, property damage or damages of any kind, whether direct, consequential, or contingent to property. Without limiting the generality of the foregoing, Degelman shall not be liable for damages resulting from any cause beyond its reasonable control, including, without limitation, loss of crops, any expense or loss of labour, supplies, rental machinery or loss of use.

No other warranty of any kind whatsoever, express or implied is made with respect to this sale; and all implied warranties of merchantability and fitness for a particular purpose which exceed the obligations set forth in this written warranty are hereby disclaimed and excluded from this sale. This exclusion shall not apply in any jurisdiction where it is not permitted by law.

### ***This limited warranty shall not apply:***

1. If, in the sole opinion of Degelman, the unit has been subjected to misapplication, abuse, misuse, negligence accident or incorrect off-site machine set-up.
2. To any goods that have sustained damage or deterioration attributable to a lack of routine maintenance (eg. Check and Re-torque of fastening hardware, Hydraulic fluid purities, drive train alignments, and clutch operation)
3. If parts not made or supplied by Degelman have been used in the connection with the unit, if, in the sole judgement of Degelman such use affects its performance, safety, stability or reliability.
4. If the unit has been altered or repaired outside of an authorized Degelman dealership in a manner which, in the sole judgement of Degelman, affects its performance, safety, stability or reliability.
5. To expendable or wear items such as (eg. Harrow tines, Rock Picker and Rock Rake wear teeth and replaceable bushings and pins.) and any other items that in the company's sole judgement are a wear item.

No employee or representative of Degelman Industries LP is authorized to change this limited warranty in any way or grant any other warranty unless such change is made in writing and signed by the Degelman Service Manager.

This limited warranty is subject to any future availability of supply, which may directly affect Degelman's ability to obtain materials or manufacture replacement parts.

Degelman reserves the right to make improvements in design or changes in specifications at any time, without incurring obligations to owners of equipment previously delivered.

This limited warranty is subject to compliance by the customer to the enclosed *Retail Customer's Responsibility Under Degelman Warranty*.

# Warranty

---

## **Retail Customer's Responsibility Under Degelman Warranty.**

It is the retail customer and/or Operator's responsibility to read the Operator's Manual, to operate, lubricate, maintain and store the equipment in accordance with all instructions and safety procedures. Failure of the operator to read the operators manual is a misuse of this equipment.

It is the retail customer and/or operators responsibility to inspect the product and to have any part(s) repaired or replaced when continued operation would cause damage or excessive wear to other parts or cause safety hazard.

It is the retail customer's responsibility to deliver the product to the authorized Degelman dealer, from whom he purchased it, for service or replacement of defective parts, which are covered by warranty. Repairs to be submitted for warranty consideration must be made within forty-five days of failure.

It is the Retail Customer's responsibility for any cost incurred by the dealer for hauling of the product for the purpose of performing a warranty obligation or inspection.

## **WARRANTY INFORMATION**

---

**Make certain the warranty registration card has been forwarded to:**

**Degelman Industries LP**  
**Box 830 -272 Industrial Dr.**  
**Regina, SK, Canada**  
**S4P 3B1**

Always give your dealer the serial number of your Degelman product when ordering parts or requesting service or other information.

The serial number is located on the machine as shown in the diagram below. In the space provided record the model number, the serial number and the date of purchase to assist your dealer in providing you with prompt and efficient service.

SERIAL NUMBER: \_\_\_\_\_

MODEL NUMBER: \_\_\_\_\_

DATE OF PURCHASE: \_\_\_\_\_



Serial Number  
Plate Location



