



LANDROLLER



LANDROLLER | 45 | 51

142692 v1.1

DEGELMAN INDUSTRIES LP
BOX 830-272 INDUSTRIAL DRIVE,
REGINA, SK, CANADA, S4P 3B1
FAX 306.543.2140 PH 306.543.4447
1.800.667.3545 DEGELMAN.COM

TRI-PLEX LANDROLLER
45/51

SN: LR8167 and up

QUICK-START GUIDE*

for LANDROLLER 45 | 51

* Refer to operators manual for complete safety and operation info.



Degelman

A Connect Hydraulics



① ROLLER LIFT CIRCUIT.....End Wheel Cylinders

② CENTER WHEELS.....Center Wheel Cylinders


B Backing Into Field Position

- 1) Drive landroller onto level ground, straight behind the tractor.
 - Ensure there is plenty of room behind and to the sides of the landroller for backing into field position.
- 2) Remove all five red transport bars. (4 located on cylinders, and 1 on float hitch).
 - Place the transport bars onto the storage brackets provided and secure with lock-pin.


Note: You may need to activate (extend) the hydraulic cylinders to allow removal of the cylinder transport bars.




- 3) Raise the floatation plate to allow an 1-1/4" gap using the ratchet jack to place it into field "float" position. Float position will allow the hitch pole to contour more effectively and prevent strain and possible damage to the machine.
- 4) Activate the End Wheel Circuit ① to start lowering the drums to the ground but **stop lowering** before the drums make contact with the ground.




- 5) Slowly back-up the landroller spreading the wings until they are almost fully in field position.




- 6) Fully lower the drums to the ground and raise endwheel struts by closing the hydraulic cylinders ① & ②.



- 7) Continue backing up until Swing-Arms lock in place.




- 8) The roller is now in field ready position.




C Moving Into Transport Position


- 1) On level ground, extend center wheel lift cylinders ② to fully lift rollers off ground. (This will tighten autofold cables and open the "Swing Arm" latches.)
- 2) Extend end wheel circuit ① to fully lift wing rollers off the ground.
- 3) Drive forward until roller wings trail behind.



- 4) Install the four cylinder transport bars onto the center & end wheel cylinder shafts and secure.



- 5) Close the floatation plate using the ratchet jack and secure into transport position with the red transport pin.



- 6) Read and follow necessary safety procedures outlined in "Transport Safety" section of the manual.



Maintenance

(Check Machine Daily)

- Check for missing, worn or damaged parts.
- Working points & pins
- Hydraulic Connections & Hoses
- Hubs & Spindles

* Refer to operators manual for complete safety and operation info.

LANDROLLER | 45 | 51

** Reference Sheet Quick-Start Guide*

OPERATORS SECTION - TABLE OF CONTENTS


Introduction	1
Safety	2
Operation	4
<i>Transport to Field Position</i>	<i>7</i>
<i>Field to Transport Position</i>	<i>8</i>
Service & Maintenance	9
<i>Service / Maintenance Checklist</i>	<i>11</i>
<i>Repair - Hydraulic Cylinder</i>	<i>12</i>
<i>Repair - Auto-fold Cable Tension</i>	<i>15</i>
<i>Repair - Wheel Hub</i>	<i>16</i>
Troubleshooting	17

PARTS SECTION - TABLE OF CONTENTS

<i>Hitch Frame Components</i>	<i>18</i>
<i>Center Frame Components</i>	<i>19</i>
<i>Center Wheel & Swing Arm Components</i>	<i>20</i>
<i>Endwheel Components</i>	<i>21</i>
<i>Wing Frame Components</i>	<i>22</i>
<i>Hydraulic & Electrical Routing</i>	<i>23</i>
 Warranty	 26



LANDROLLER | 45 | 51



CONGRATULATIONS on your choice of a Degelman Landroller to complement your farming operation. It has been designed and manufactured to meet the needs of a discerning agricultural market for increasing yields for high quality pulse crops and preparing the perfect bed for haying, grasses and silage. Degelman rollers provide a smooth and level surface for faster, easier harvest operations and better seed-to-soil contact. Use this manual as your first source of information about this machine.

Safe, efficient and trouble free operation of your Degelman Landroller requires that you and anyone else who will be operating or maintaining it, read and understand the Safety, Operation, Maintenance and Troubleshooting information contained within this manual.

Keep this manual handy for frequent reference and to pass on to new operators or owners. Call your Degelman Dealer if you need assistance, information, or additional copies of the manual.

OPERATOR ORIENTATION - The directions left, right, front and rear, as mentioned throughout the manual, are as seen from the tractor drivers' seat and facing in the direction of travel.

Why is **SAFETY** important to **YOU**?

3 **BIG** Reasons:

- **Accidents Can Disable and Kill**
- **Accidents Are Costly**
- **Accidents Can Be Avoided**



SAFETY ALERT SYMBOL

The **Safety Alert Symbol** identifies important safety messages applied to the Landroller and in this manual. When you see this symbol, be alert to the possibility of **injury or death**. Follow the instructions provided on the safety messages.

The **Safety Alert Symbol** means:

ATTENTION!
BECOME ALERT!
YOUR SAFETY IS INVOLVED!

SIGNAL WORDS

Note the use of the Signal Words: **DANGER**, **WARNING**, and **CAUTION** with the safety messages. The appropriate Signal Word has been selected using the following guidelines:



DANGER: Indicates an imminently hazardous situation that, if not avoided, **WILL** result in death or serious injury if proper precautions are not taken.



WARNING: Indicates a potentially hazardous situation that, if not avoided, **COULD** result in death or serious injury if proper precautions are not taken.



CAUTION: Indicates a potentially hazardous situation that, if not avoided, **MAY** result in minor or moderate injury if proper practices are not taken, or, serves as a reminder to follow appropriate safety practices.

SAFETY

YOU are responsible for the safe operation and maintenance of your Degelman Landroller. **YOU** must ensure that you and anyone else who is going to operate, maintain or work around the Landroller be familiar with the operating and maintenance procedures and related **SAFETY** information contained in this manual. This manual will take you step-by-step through your working day and alerts you to all good safety practices that should be adhered to while operating this equipment.

Remember, **YOU** are the key to safety. Good safety practices not only protect you but also the people around you. Make these practices a working part of your safety program. Be certain that **EVERYONE** operating this equipment is familiar with the recommended operating and maintenance procedures and follows all the safety precautions. Most accidents can be prevented. Do not risk injury or death by ignoring good safety practices.

- Landroller owners must give operating instructions to operators or employees before allowing them to operate the Landroller, and at least annually thereafter per OSHA regulation 1928.51.
- The most important safety device on this equipment is a SAFE operator. It is the operator's responsibility to read and understand ALL Safety and Operating instructions in the manual and to follow these. All accidents can be avoided.
- A person who has not read and understood all operating and safety instructions is not qualified to operate the machine. An untrained operator exposes himself and bystanders to possible serious injury or death.
- Do not modify the equipment in any way. Unauthorized modification may impair the function and/or safety and could affect the life of the equipment.
- Think SAFETY! Work SAFELY!

GENERAL SAFETY

1. Read and understand the Operator's Manual and all safety signs before operating, maintaining or adjusting the Landroller.



2. Install and properly secure all shields and guards before operating. Use hitch pin with a mechanical locking device.

3. Have a first-aid kit available for use should the need arise and know how to use it.




4. Have a fire extinguisher available for use should the need arise and know how to use it.



5. Wear appropriate protective gear. This list includes but is not limited to:

- A hard hat
- Protective shoes with slip resistant soles
- Protective glasses or goggles
- Heavy gloves
- Wet weather gear
- Hearing protection
- Respirator or filter mask



6. Clear the area of people, especially small children, and remove foreign objects from the machine before starting and operating.
7. Do not allow riders.
8. Stop tractor engine, set park brake, remove ignition key and wait for all moving parts to stop before servicing, adjusting, repairing or unplugging.
9. Review safety related items with all operators annually.

Operation


TO THE NEW OPERATOR OR OWNER

The Degelman Landroller is designed to provide a smooth and level surface.

It is the responsibility of the owner or operator to read this manual carefully to learn how to operate the machine safely. Safety is everyone's business. By following safe operating practices, a safe environment is provided for the operator and bystanders.

By following the operating instructions in conjunction with a good maintenance program your machine will provide many years of trouble-free service.


Transport Position



OPERATING SAFETY

1. Read and understand the Operator's Manual and all safety signs before using.
2. Stop tractor engine, set park brake, remove ignition key and wait for all moving parts to stop before servicing, adjusting, repairing or unplugging.
3. Keep hands, feet, hair and clothing away from all moving and/or rotating parts.
4. Do not allow riders on the Landroller tractor during operation or transporting.
5. Keep all shields and guards in place when operating (if applicable).
6. Clear the area of all bystanders, especially children, before starting.
7. Do not operate machine on overly steep side hills or slopes.
8. Be careful when working around or maintaining a high-pressure hydraulic system. Ensure all components are tight and in good repair before starting.
9. Clean all reflectors, lights and the SMV sign before transporting on a highway or public road. Be sure to check with local highway authorities and comply with their lighting requirements.

Field Position



Operation

BREAK-IN

Although there are no operational restrictions on the Landroller when it is new, there are some checks that should be done when using the machine for the first time, follow this procedure:

⚠ IMPORTANT: *It is important to follow the Break-In procedures especially those listed in the "Before using" section below to avoid damage:*

A. Before using:

1. Read Safety Info. & Operator's Manual.
2. Complete steps in "Pre-Operation Checklist".
3. Lubricate all grease points.

Note: Do **NOT** grease the **bearings** on the roller ends as they come pre-lubricated and sealed from the factory (even though some previous spherical bearing units may have had grease fittings, do not grease them.)


4. Check all bolt tightness.

B. After operating for 2 hours:

1. Check all hardware. Tighten as required.
2. Check all hydraulic system connections. Tighten if any are leaking.

PRE-OPERATION CHECKLIST

It is important for both personal safety and maintaining good operational condition of the machine that the pre-operational checklist be followed.

Before operating the machine and each time thereafter, the following areas should be checked off: 

1. Lubricate the machine per the schedule outlined in the "Maintenance Section".
2. Use only a tractor with adequate power to pull the Landroller under ordinary operating conditions.
3. Ensure that the machine is properly attached to the tractor using a drawbar pin with provisions for a mechanical retainer. Make sure that a retainer such as a Klik pin is installed.

NOTE: *It is important to pin the draw bar in the central location only.*

4. Before using, inflate tires to:

45 Model - Center Tires

9.5L x15 - 8 PLY: **60 PSI (414 kPa)** - or -

9.5L x15 - 6 PLY: **36 PSI (248 kPa)** (alternate tire)

45 Model - Endwheel Tires

9.5L x15 - 8 PLY: **60 PSI (414 kPa)** - or -

9.5L x15 - 6 PLY: **36 PSI (248 kPa)** (alternate tire)

51 Model - Center Tires

11L x15 - 12 PLY: **90 PSI (620 kPa)**

51 Model - Endwheel Tires

12.5L x15 - 12 PLY: **90 PSI (620 kPa)**

5. Ensure that a safety chain is installed on the hitch.
6. Check oil level in the tractor hydraulic reservoir. Top up as required.
7. Inspect all hydraulic lines, hoses, fittings and couplers for tightness. Tighten if there are leaks. Use a clean cloth to wipe any accumulated dirt from the couplers before connecting to the tractor's hydraulic system.

Operation

HOOK-UP / UNHOOKING

The Landroller should always be parked on a level, dry area that is free of debris and foreign objects. Follow this procedure to hook-up:

1. Clear the area of bystanders and remove foreign objects from the machine and working area.
2. Make sure there is enough room to back the tractor up to the trailer hitch.
3. Start the tractor and slowly back it up to the hitch point.
4. Stop the tractor engine, place all controls in neutral, set park brake and remove ignition key before dismounting.
5. Use the jack to raise or lower the hitch to align with the drawbar.
6. Install a drawbar pin with provisions for a mechanical retainer such as a KLIK pin. Install the retainer.
7. Install a safety chain between the tractor and the hitch.
8. Connect the hydraulics. To connect, proceed as follows:
 - Use a clean cloth or paper towel to clean the couplers on the ends of the hoses. Also clean the area around the couplers on the tractor. Remove the plastic plugs from the couplers and insert the male ends.
 - Be sure to match the pressure and return line to one valve bank.
9. Connect lights (electrical socket plug) to tractor.
10. Raise the hitch jack and rotate it 90° to place in its stowed position.
11. When unhooking from the tractor, reverse the above procedure.

TRANSPORT SAFETY

1. Read and understand ALL the information in the Operator's Manual regarding procedures and SAFETY when operating the Landroller in the field/yard or on the road.
2. Check with local authorities regarding machine transport on public roads. Obey all applicable laws and regulations.
3. Always travel at a safe speed. Use caution when making corners or meeting traffic.
4. Make sure the SMV (Slow Moving Vehicle) emblem and all the lights and reflectors that are required by the local highway and transport authorities are in place, are clean and can be seen clearly by all overtaking and oncoming traffic.
5. Keep to the right and yield the right-of-way to allow faster traffic to pass. Drive on the road shoulder, if permitted by law.
6. Always use hazard warning flashers on tractor when transporting unless prohibited by law.
7. Always use a pin with provisions for a mechanical retainer and a safety chain when attaching to a tractor or towing vehicle.

TRANSPORTING

Use the following guidelines while transporting the Landroller:

1. Use a safety chain.
2. Ensure all transport locks are securely in place.
3. Be sure hazard lights are flashing and SMV decal is visible.
4. MAXIMUM RECOMMENDED TRANSPORT SPEED: 30 km/h or 19 mph. (Road Conditions. Field speeds may be lower.)


⚠ IMPORTANT: UNDER NO CIRCUMSTANCES SHOULD THERE EVER BE RIDERS WHILE THE LANDROLLER IS IN TRANSPORT.



Operation


TRANSPORT TO FIELD POSITION

1. Drive the landroller onto level ground so it is straight behind the tractor.




2. Remove all five red transport bars. (4 located on cylinders, and 1 on float hitch). You may need to activate (extend) the hydraulic cylinders to allow removal of the cylinder transport bars.


Place the transport bars onto the storage brackets provided and secure with lock-pin.




3. Raise the floatation plate to allow an 1-1/4" gap using the ratchet jack to place it into field "float" position. Float position will allow the hitch pole to contour more effectively and prevent strain and possible damage to the machine.




4. Activate the End Wheel Circuit to start lowering the drums to the ground but **stop lowering** before the drums make contact with the ground.




5. Slowly back-up the landroller spreading the wings until they are almost fully in field position.




6. Fully lower the drums to the ground and raise endwheel struts by closing the hydraulic cylinders.



7. Continue backing up until Swing-Arms lock in place.




8. The roller is now in field ready position.




Operation

FIELD TO TRANSPORT POSITION


1. On level ground, extend center wheel lift cylinders to fully lift rollers off ground. (This will tighten autofold cables and open the "Swing Arm" latches.)
2. Extend end wheel circuit to fully lift wing rollers off the ground.
3. Drive forward until roller wing trail behind.



4. Install the 4 cylinder transport bars onto the center & endwheel cylinder shafts and secure.



5. Close the floatation plate using the Ratchet jack and secure into transport position with the red transport pin.



6. Follow necessary safety procedures outlined in "Transport Safety" section of the manual.


Service & Maintenance

MAINTENANCE SAFETY

1. Review the Operator's Manual and all safety items before working with, maintaining or operating the Landroller.
2. Stop the tractor engine, set park brake, remove ignition key and wait for all moving parts to stop before servicing, adjusting, repairing or unplugging.
3. Keep hands, feet, clothing and hair away from all moving and/or rotating parts.
4. Clear the area of bystanders, especially children, when carrying out any maintenance and repairs or making any adjustments.
5. Place safety stands or large blocks under the frame before removing tires or working beneath the machine.
6. Be careful when working around or maintaining a high-pressure hydraulic system. Wear proper eye and hand protection when searching for a high pressure hydraulic leak. Use a piece of wood or cardboard as a backstop when searching for a pin hole leak in a hose or a fitting.
7. Always relieve pressure before disconnecting or working on hydraulic system.

HYDRAULIC SAFETY

1. Always place all tractor hydraulic controls in neutral before dismounting.
2. Make sure that all components in the hydraulic system are kept in good condition and are clean.
3. Replace any worn, cut, abraded, flattened or crimped hoses and metal lines.
4. Do not attempt any makeshift repairs to the hydraulic lines, fittings or hoses by using tape, clamps or cements. The hydraulic system operates under extremely high-pressure. Such repairs will fail suddenly and create a hazardous and unsafe condition.
5. Wear proper hand and eye protection when searching for a high-pressure hydraulic leak. Use a piece of wood or cardboard as a backstop instead of hands to isolate and identify a leak.
6. If injured by a concentrated high-pressure stream of hydraulic fluid, seek medical attention immediately. Serious infection or toxic reaction can develop from hydraulic fluid piercing the skin surface.
7. Before applying pressure to the system, make sure all components are tight and that lines, hoses and couplings are not damaged.



- Think SAFETY! Work SAFELY

Service & Maintenance

TORQUE SPECIFICATIONS

CHECKING BOLT TORQUE

The tables shown below give correct torque values for various bolts and capscrews. Tighten all bolts to the torques specified in chart unless otherwise noted. Check tightness of bolts periodically, using bolt torque chart as a guide. Replace hardware with the same strength (Grade/Class) bolt.

IMPERIAL TORQUE SPECIFICATIONS

(based on "Zinc Plated" values)



SAE-5



SAE-8

Size	Grade 5 lb. ft (N.m)	Grade 8 lb. ft (N.m)
1/4"	7 (10)	10 (14)
5/16"	15 (20)	20 (28)
3/8"	25 (35)	35 (50)
7/16"	40 (55)	60 (80)
1/2"	65 (90)	90 (120)
9/16"	90 (125)	130 (175)
5/8"	130 (175)	180 (245)
3/4"	230 (310)	320 (435)
7/8"	365 (495)	515 (700)
1"	550 (745)	770 (1050)
1-1/8"	675 (915)	1095 (1485)
1-1/4"	950 (1290)	1545 (2095)
1-3/8"	1250 (1695)	2025 (2745)
1-1/2"	1650 (2245)	2690 (3645)

METRIC TORQUE SPECIFICATIONS

(based on "Zinc Plated" values)



8.8



10.9

Size	Class 8.8 lb. ft (N.m)	Class 10.9 lb. ft (N.m)
M6	7 (10)	10 (14)
M8	16 (22)	23 (31)
M10	30 (42)	45 (60)
M12	55 (75)	80 (108)
M14	90 (120)	125 (170)
M16	135 (185)	195 (265)
M18	190 (255)	270 (365)
M20	265 (360)	380 (515)
M22	365 (495)	520 (705)
M24	460 (625)	660 (895)
M27	675 (915)	970 (1315)
M30	915 (1240)	1310 (1780)
M33	1250 (1695)	1785 (2420)
M36	1600 (2175)	2290 (3110)

HARDWARE/HOSE SPECIFICATIONS



Unless otherwise stated:


- Hardware - Hex, Plated GR5 UNC or P8.8 (metric)
- Hydraulic Hoses - 3/8 & 1/2, ends come with 3/4 JIC female swivel.

WHEEL NUT & WHEEL BOLT TORQUE


BOLT PATTERNS




5 BOLT PATTERN



6 BOLT PATTERN



8 BOLT PATTERN



10 BOLT PATTERN

Wheel Nut/Bolt Torque

Size	lb. ft (N.m)
9/16	120-130 (165-175)
5/8	185-190 (250-260)
3/4	280-300 (380-405)

Wheel Tightening Procedure

1. Install and **hand tighten** nuts/bolts.
2. Tighten to approx **20% Torque** value using the 10 Bolt **Star or CrissCross** pattern shown above.
3. Tighten to **Full Torque** value using the **Star or CrissCross** pattern.
4. If applicable, install **Rear Locknuts** using **Wheel Torque Values**.

HYDRAULIC FITTING TORQUE

Hydraulic Fitting Torque*

Size	lb. ft (N.m)
1/2	34 (46)
3/4	75 (100)
7/8	90 (122)

* The torque values shown are based on lubricated connections as in reassembly.

Tightening Flare Type Tube Fittings

1. Check flare and flare seat for defects that might cause leakage.
2. Align tube with fitting before tightening.
3. Lubricate connection and hand tighten swivel nut until snug.
4. To prevent twisting the tube(s), use two wrenches. Place one wrench on the connector body and with the second tighten the swivel nut to the torque shown.

Service & Maintenance

SERVICE

GREASING

Grease: Use an SAE multipurpose grease with extreme pressure (EP) performance. Also acceptable is an SAE multipurpose lithium.

1. Use only a hand-held grease gun for all greasing.
2. Wipe grease fitting with a clean cloth before greasing, to avoid injecting dirt.
3. Replace and repair broken fittings immediately.
4. If fittings will not take grease, remove and clean thoroughly. Also clean lubricant passageway. Replace fitting if necessary.
5. Inject grease until you see grease being expelled from the bearing or bushing areas.

Note: Do **NOT** grease the **bearings** on the roller ends as they come pre-lubricated and sealed from the factory (even though some previous spherical bearing units may have had grease fittings, do not grease them.)



SAFETY DECALS & REFLECTORS

Keep safety decals and signs clean and legible at all times. Replace safety decals and signs that are missing or have become illegible. Safety decals or signs are available from your Dealer Parts Department.

- 142383 - Decal, Caution, 1-6 Point Safety (1)
- 142422 - Decal, Danger - Stay Clear Crush (1)
- 142454 - Decal, Important, Float Plate Position (1)
- 142387 - Decal, Remove Red Bar (4)
- 142557 - Decal, Reflector Amber - 2 x 9 (8)
- 142556 - Decal, Reflector Red - 2 x 9 (3)
- 142650 - Decal, Reflector Fluorescent - 2 x 9 (3)
- 142492 - Decal, Patent - Bent Axle (2)
- 142455 - Decal, Endwheel Positioning (2)
- 142008 - Decal, Degelman (3)
- 142768 - Decal, Landroller 45 (2) or
- 142769 - Decal, Landroller 51 (2)

Previous:

- 142280 - Decal, Reflector Red - 2 x 6-1/4 (2)


MAINTENANCE CHECKLIST

Use the Maintenance Checklist provided for regular service intervals and keep a record of all scheduled maintenance:

(Note: Do **NOT** grease roller end **bearings**)

Maintenance Check - 10 Hours

- Hydraulic fluid leaks
- Damaged hoses
- Check tire pressure:



Center Tires - 45 Model

9.5L x15 - 8 PLY: **60 PSI (414 kPa)** - or -
9.5L x15 - 6 PLY: **36 PSI (248 kPa)** (alt.)



Center Tires - 51 Model

11L x15 - 12 PLY: **90 PSI (620 kPa)**

Endwheel Tires - 45 Model

9.5L x15 - 8 PLY: **60 PSI (414 kPa)** - or -
9.5L x15 - 6 PLY: **36 PSI (248 kPa)** (alt.)

Endwheel Tires - 51 Model

12.5L x15 - 12 PLY: **90 PSI (620 kPa)**

Grease Points - 25 Hours

- Front Hitch Frame Pins
- Floatation Plate Pin
- Cast Bearings (**not** roller end bearings)
- Swing-Arm Holders
- Cylinder Pins
- Cross Joint Pins



Grease Points - 50 Hours

- Endwheel Strut & Linkage Pins
- Hubs & Spindles
- Working points & pins
- Safety signs clean



Annually

- Bolt tightness
- Wheel bearings
- Latch mechanism
- Cable assembly

Service & Maintenance

HYDRAULIC CYLINDER REPAIR

PREPARATION

When cylinder repair is required, clean off unit, disconnect hoses and plug ports before removing cylinder.

When removed, open the cylinder ports and drain the cylinder's hydraulic fluid.



Examine the type of cylinder. Make sure you have the correct tools for the job.

You may require the following tools:

- Proper **Seal Kit**
- Rubber Mallet
- Screwdriver
- Punch
- Pliers
- Emery cloth
- Torque Wrench


Types of Cylinders

(Wire Ring / Threaded Head)




REPAIRING A WIRE RING CYLINDER

1. Retract the rod assembly.
2. Remove the external steel wire ring.




3. Remove any dirt that may have accumulated on the cylinder head.

4. Using the mallet and punch, push the head into the cylinder tube until the internal tube groove is fully exposed. This will also move the internal wire ring into its removal position.




5. Take the plastic removal ring from the seal kit:
 - a) Straighten the ring and remove any kinks or excessive curl to make installation easier and prevent it from falling out.
 - b) Insert the removal ring into the internal groove with the feathered end pointing into the tube.



- c) Use a screwdriver or a finger to hold one end of the ring in the groove while fitting the other end of the ring into the groove. The tips should snap in together. Ensure it is secure and fully seated before the next step.

IMPORTANT: It is important to ensure the removal ring is completely in the groove before pulling the rod out. If the ring sticks out it will get stuck between the head and tube.


6. a) Extend the rod to pull head out of tube. If the rod does not pull out easily, push the head back in and ensure the ring is properly in the groove. Replace ring if necessary.



Note: Excessive force will not overcome a jammed ring and could damage the cylinder.


- b) Completely remove rod and head from tube.

7. Remove plastic removal ring from the cylinder tube.




Service & Maintenance

8. Remove locknut, piston and head from rod.




9. a) Inspect and replace all of the seals with new components.
 b) Inspect the inside of the cylinder barrel, piston, rod and other polished parts for burrs and scratches. Smooth areas as needed with an emery cloth.
 c) During re-assembly of head/gland assembly, leave the outer O-Ring Dual Seal loose on the rod to re-install at a later step.
10. Replace piston and torque the locknut to required value. (Refer to chart below)



LOCKNUT SIZE (PISTON)	TORQUE VALUE
3/8 - 24 UNF	25-30 lb.ft (35-42 N.m)
1/2 - 20 UNF	40-60 lb.ft (55-80 N.m)
5/8 - 18 UNF	95-105 lb.ft (130-140 N.m)
3/4 - 16 UNF	175-225 lb.ft (240-305 N.m)
7/8 - 14 UNF	200-275 lb.ft (270-370 N.m)
1 - 14 UNF	300-380 lb.ft (405-515 N.m)
1 1/8 - 12 UNF	400-500 lb.ft (540-675 N.m)
1 1/4 - 12 UNF	500-600 lb.ft (675-810 N.m)
1 1/2 - 12 UNF	700-800 lb.ft (950-1085 N.m)
1 3/4 - 12 UNF	800-900 lb.ft (1085-1220 N.m)


11. a) Install the supplied band clamp to compress the inner wire ring on the head/gland assembly so it will fit into the tube.
- Note:** Make sure the cam of the band clamp is not overtop of the gap in the ring.



- b) Tighten the band clamp to ensure the wire ring is fully seated. Then, loosen the clamp approx. 1/2 a turn to allow band clamp to slide during final assembly.

12. Lubricate the cylinder tube and piston seals.


13. Insert the piston into the tube. Tap the cylinder head into the tube until the clamp slides over and the inner wire ring is inside the tube.




14. Loosen the clamp and remove.

15. Install the O-Ring Dual seal.


16. Tap the head the rest of the way until the end is flush with the tube.



IMPORTANT: The head/gland must be inserted until it is flush with the tube to allow the inner wire ring to snap into its seated position in the internal cylinder groove. Failure to insert the head flush as shown will result in the head and rod assembly coming out of the tube when pressure is applied to the cylinder.



17. Pull the rod out to expose the external wire ring groove in cylinder head, and then install the external ring.




18. Before using the cylinder, ensure that you double check your work.

Service & Maintenance

REPAIRING A THREADED HEAD CYLINDER

Set Screw Style



DISASSEMBLY

1. Loosen Set Screw and turn off end cap.
2. Carefully remove piston/rod/gland assemblies.
3. Disassemble the piston from the rod assembly by removing lock nut.

NOTE: DO NOT clamp rod by chrome surface.

4. Slide off gland assembly & end cap.
5. Remove seals and inspect all parts for damage.
6. Install new seals and replace damaged parts with new components.
7. Inspect the inside of the cylinder barrel, piston, rod and other polished parts for burrs and scratches. Smooth areas as needed with an emery cloth.

REASSEMBLY

1. Reinstall rod through end cap & gland assembly.
2. Secure piston to rod with lock nut. Torque lock nut to proper value (refer to chart on previous page for proper torque value).
3. Lube inside of barrel, piston seals, and gland seals with hydraulic oil.
4. With cylinder body held gently in a vise, insert piston, gland, end cap and rod combination using a slight rocking motion.
5. Apply Loctite anti-seize before installing cylinder end cap.
6. Torque cylinder end cap to 440 lb.ft (600 N.m).
7. Tighten Set Screw on end cap to 6 lb.ft (8 N.m).

Service & Maintenance

TIRE SAFETY

1. Failure to follow proper procedures when mounting a tire on a wheel or rim can produce a blow out which may result in serious injury or death.
2. Do not attempt to mount a tire unless you have the proper equipment and experience to do the job.
3. Have a qualified tire dealer or repair serviceman perform required tire maintenance.

TIRE SPECIFICATIONS

Center Tires - 45 Model

9.5L x15 - 8 PLY: **60 PSI (414 kPa)** - or -
9.5L x15 - 6 PLY: **36 PSI (248 kPa)** (alternate tire)

Center Tires - 51 Model

11L x15 - 12 PLY: **90 PSI (620 kPa)**

Endwheel Tires - 45 Model

9.5L x15 - 8 PLY: **60 PSI (414 kPa)** - or -
9.5L x15 - 6 PLY: **36 PSI (248 kPa)** (alternate tire)

Endwheel Tires - 51 Model

12.5L x15 - 12 PLY: **90 PSI (620 kPa)**


STORAGE

The landroller should be carefully prepared for storage to ensure that all dirt, mud, debris and moisture has been removed.

Follow this procedure when preparing to store:


1. Wash the entire machine thoroughly using a water hose or pressure washer to remove all dirt, mud, debris or residue.
2. Inspect all parts to see if anything has become entangled in them. Remove the entangled material.
3. Lubricate all grease fittings to remove moisture (except spherical bearings - refer to pg.11)
4. Inspect all hydraulic hoses, fittings, lines and couplers. Tighten any loose fittings. Replace any hose that is badly cut, nicked or abraded or is separating from the crimped end of the fitting.
5. Touch up all paint nicks and scratches to prevent rusting.
6. Oil the exposed rams on the hydraulic cylinder to prevent rusting.
7. Select an area that is dry, level and free of debris.

AUTOFOLD LATCH ADJUSTMENT



If the Autofold Latch will no longer fully open enough to release the Swing Arm for transport, this may be due to the slight stretching of the autofold cable. To Adjust:


- 1) Place Landroller into Field Position (wings out) with the Swing Arm in the latched (secured) position.
- 2) Lower the wheels raising the drums off the ground. (This should open the Autofold latch in order for the Swing Arms to release. If the latch does not open enough to allow the swing arm(s) to release, continue to the next step.)
- 3) Adjust the nut on the Eyebolt until the latch is open just enough for the Swing Arm to clear. This should be the correct amount of tension for the cable.



Service & Maintenance

WHEEL HUB REPAIR

COMMON HUB & SPINDLE COMPONENTS



⚠ IMPORTANT: *Be sure to block up unit securely before removing tires.*

DISASSEMBLY

1. Remove dust cap.
2. Remove cotter pin from nut.
3. Remove nut and washer.
4. Pull hub off spindle.
5. Dislodge the inner cone bearing and dust seal.
6. Inspect cups that are press fitted into hub for pits or corrosion and remove if necessary.
7. Inspect and replace defective parts with new ones.

ASSEMBLY

1. If cups need replacing, be careful to install them gently and evenly into hub until they are fully seated.
2. Apply a thick wall of grease inside hub. Pack grease in cones.
3. Install inner cone and dust seal as illustrated.
4. Position hub onto spindle and fill surrounding cavity with grease.
5. Assemble outer cone, washer and nut.
6. Tighten nut while rotating hub until there is a slight drag.
7. Turn nut back approximately 1/2 turn to align cotter pin hole with notches on nut.
8. Install cotter pin and bend legs sideways over nut.
9. Fill dust cap half full of grease and gently tap into position.
10. Pump grease into hub through grease fitting until lubricant can be seen from dust seal.


Troubleshooting

GENERAL TROUBLESHOOTING


SYMPTOM	PROBLEM	SOLUTION
Uneven ground contour, and more compaction on the center section of the Landroller.	The center hitch frame is not in the float position.	Ensure that the Landroller front hitch frame float plate has been placed into the float position using the ratchet jack. Float plate gap should be raised to approx. 1-1/4".
When driving in the field position, the wings fall back.	When putting the Landroller into field position it is not latching correctly.	Ensure the Landroller is on level ground when backing up to the latch mechanism, and that the swing-arms fully engage into the latches. The transport wheels <u>must</u> be fully up in order for the latches to fully engage. If problem still occurs, adjust the eye bolt on the cable for mechanism to latch tighter.
One wing won't open up into field position.	Uneven ground, faulty relief, swing arm tubes seized and also possible binding in the cross joint area.	Ensure on level ground. Try backing up a slight slope to help assist the wings to fold out. Unhook the swing arm tube, and move manually to make sure that the swing arm is not seized. If problem stays contact your local Degelman dealer.
Landroller rollers won't turn.	Material build-up around rollers. If it is only one roller that doesn't turn, it might be a faulty bearing.	Ensure that there is no material build-up around rollers.
Excessive play or excessive binding in rockshaft area (center frame wheel assembly).	Cast support blocks around rockshaft not correctly adjusted.	Lower the rollers to the ground and lift the transport wheels off the ground. Check if the play in the rockshaft area is excessive. If so, remove the cap of the casting blocks around the rockshaft, and remove shims until desired clearance is needed to take the play out. Note: Do not remove too many shims, and make it too tight. If in case of binding make sure you have adequate grease in the block itself. Make sure, it's not rusted from a long time of storage in one position.

Hitch Frame Components

Front Hitch Components Detail




Rear Hitch Components Detail




Center Frame Components


Center Frame Exploded Overview



Cross Joint Component Detail




Center Frame Exploded




Center Wheel & Swing Arm Components

Swing Arms & Holders Detail



Center Frame Wheel & Tire Components



45 Models - Center Wheels

131509 - Tire Assembly (2)
 131510 - Tire, 9.5L x 15 - 8 PLY (1)
 131001 - Rim, 15 x 8 - 6 Bolt (1)
 127006 - Valve Stem - TR415 (1)

Tire Pressure - 60 PSI (414 kPa)

- or -

Alternate Tire Assembly

131062 - Tire Assembly (2)
 127003 - Tire, 9.5L x 15 - 6 PLY (1)
 131001 - Rim, 15 x 8 - 6 Bolt (1)
 127006 - Valve Stem - TR415 (1)


Tire Pressure - 36 PSI (248 kPa)

51 Models - Center Wheels


131600 - Tire Assembly (2)
 131601 - Tire, 11L x 15-12 PLY (1)
 131001 - Rim, 15 x 8 - 6 Bolt (1)
 127016 - Valve Stem - TR416 (1)

Tire Pressure - 90 PSI (620 kPa)

Hub/Spindle Assembly (131324)



Endwheel Components



End Wheel Tire Options

End Wheel Options - 45 Models

- 131509 - Tire Assembly (2)
- 131510 - Tire, 9.5L x 15 - 8 PLY (1)
- 131001 - Rim, 15 x 8 - 6 Bolt (1)
- 127006 - Valve Stem - TR415 (1)

Tire Pressure - 60 PSI (414 kPa)

- or -

Alternate Tire Assembly

- 131062 - Tire Assembly (2)
- 127003 - Tire, 9.5L x 15 - 6 PLY (1)
- 131001 - Rim, 15 x 8 - 6 Bolt (1)
- 127006 - Valve Stem - TR415 (1)


Tire Pressure - 36 PSI (248 kPa)

End Wheels - 51 Models

- 131515 - Tire Assembly (2)
- 127018 - Tire, 12.5L x 15 - 12 PLY (1)
- 131328 - Rim, 15 x 10 - 6 Bolt (1)
- 127006 - Valve Stem - TR415 (1)


Tire Pressure - 90 PSI (620 kPa)

End Wheel Cylinder Transport Lock Components




Wing Frame Components

Wing Frame Overview



Truss Support Detail - 51 Models




Hydraulic Routing - Center Wheels

Hydraulic Fittings Required


- | | | | |
|---|--|---------------------------------------|-----|
| 1 | | 141581 - Quick Coupler-m - 3/4 ORB | (2) |
| 2 | | 141676 - Nipple, 3/4 ORB-m | (2) |
| 3 | | 141682 - Coupler, Blue (+) | (1) |
| 4 | | 141683 - Coupler, Blue (-) | (1) |
| 5 | | 141515 - Connector, 3/4 JIC-m x ORB | (2) |
| 6 | | 141504 - Elbow, 90° 3/4 JIC m x ORB m | (4) |
| 7 | | 141501 - Tee, 3/4 JIC m | (2) |

Required Hoses for Wheel Cylinders

- | | | |
|--|--------------------------|-----|
| | 126607 - Hose, 3/8 x 228 | (2) |
| | 126115 - Hose, 3/8 x 139 | (1) |
| | 126116 - Hose, 3/8 x 123 | (1) |
| | 126118 - Hose, 3/8 x 75 | (1) |
| | 126117 - Hose, 3/8 x 59 | (1) |



123700 - Cylinder, 3-1/2 x 16 x 1-1/2 (2)



Replacement Parts

123641 - Cylinder Pins Kit (1)

123652 - Seal Kit


Hydraulic Routing - End Wheels

Hydraulic Fittings Required


- | | | |
|----|--|-----|
| 1 | 141581 - Quick Coupler-m - 3/4 ORB | (2) |
| 2 | 141676 - Nipple, 3/4 ORB-m | (2) |
| 3 | 141684 - Coupler, Green (+) | (1) |
| 4 | 141685 - Coupler, Green (-) | (1) |
| 5 | 141515 - Connector, 3/4 JIC-m x ORB | (2) |
| 6 | 141504 - Elbow, 90° 3/4 JIC m x ORB m | (2) |
| 7 | 141501 - Tee, 3/4 JIC m | (2) |
| 8 | 141505 - Tee, 3/4 JIC m x m x 3/4 ORB m | (2) |
| 9 | 141518 - 90° Elbow, 3/4 JIC-m x JIC-f | (4) |
| 10 | 141560 - 90° Elbow, 3/4 JIC-m x 9/16 ORB | (2) |
| 11 | 141731 - 90° Elbow, 3/4 ORB M x M | (2) |
| 12 | 141750 - Valve, Assembly | (2) |

Required Hoses for Wheel Cylinders

- | | | | |
|-----------------|--------------------------|--------------------------|-----|
| 228 | 126607 - Hose, 3/8 x 228 | (2) | |
| 12 | 126697 - Hose, 3/8 x 12 | (2) | |
| 45' Models Only | 430 | 126124 - Hose, 3/8 x 430 | (1) |
| | 413 | 126123 - Hose, 3/8 x 413 | (1) |
| | 364 | 126125 - Hose, 3/8 x 364 | (1) |
| | 347 | 126126 - Hose, 3/8 x 347 | (1) |
| 51' Models Only | 466 | 126120 - Hose, 3/8 x 466 | (1) |
| | 449 | 126119 - Hose, 3/8 x 449 | (1) |
| | 400 | 126121 - Hose, 3/8 x 400 | (1) |
| | 383 | 126122 - Hose, 3/8 x 383 | (1) |



LH shown - RH opposite.




123414 - Cylinder, 4 x 16 x 2 (2)


123079 - Seal Kit

Electrical Routing

Light Brackets & Components



4-Wire Harness - w/plugs (1)
244599 - 45/51 Models



Warranty

2 Year **Limited Warranty - Agricultural Products**

Degelman Industries LP ("Degelman") warrants to the original purchaser of any new Degelman equipment, purchased from an authorized Degelman dealer, that the equipment will be free from defects in material and workmanship for a period of two (2) years from the date of delivery, for non-commercial use (including farm, institutional, government, and municipality) and (1) year from the date of delivery for commercial use. The obligation of Degelman to the purchaser under this warranty is limited to the repair or replacement of defective parts in the first year and to the provision, but not the installation of replacement parts in the second year. Degelman reserves the right to inspect any equipment or parts which are claimed to have been defective in material or workmanship.

This warranty limits its replacement or repair coverage to what is consistent with the warranty of Degelman's suppliers of purchased components.

Replacement or repair parts installed in the equipment covered by this limited warranty are warranted for ninety (90) days from the date of delivery of such part or the expiration of the applicable new equipment warranty period, whichever occurs later. Warranted parts shall be provided at no cost to the user at an authorized Degelman dealer during regular working hours. Warranted replacement parts will either be replaced or rebuilt at Degelman's discretion.

Disclaimer of implied warranties & consequential damages

This warranty shall not be interpreted to render Degelman Industries LP liable for injury, death, property damage or damages of any kind, whether direct, consequential, or contingent to property. Without limiting the generality of the foregoing, Degelman shall not be liable for damages resulting from any cause beyond its reasonable control, including, without limitation, loss of crops, any expense or loss of labour, supplies, rental machinery or loss of use.

No other warranty of any kind whatsoever, express or implied is made with respect to this sale; and all implied warranties of merchantability and fitness for a particular purpose which exceed the obligations set forth in this written warranty are hereby disclaimed and excluded from this sale. This exclusion shall not apply in any jurisdiction where it is not permitted by law.

This limited warranty shall not apply:

1. If, in the sole opinion of Degelman, the unit has been subjected to misapplication, abuse, misuse, negligence accident or incorrect off-site machine set-up.
2. To any goods that have sustained damage or deterioration attributable to a lack of routine maintenance (eg. Check and Re-torque of fastening hardware, Hydraulic fluid purities, drive train alignments, and clutch operation)
3. If parts not made or supplied by Degelman have been used in the connection with the unit, if, in the sole judgement of Degelman such use affects its performance, safety, stability or reliability.
4. If the unit has been altered or repaired outside of an authorized Degelman dealership in a manner which, in the sole judgement of Degelman, affects its performance, safety, stability or reliability.
5. To expendable or wear items such as (eg. Harrow tines, Rock Picker and Rock Rake wear teeth and replaceable bushings and pins.) and any other items that in the company's sole judgement are a wear item.

No employee or representative of Degelman Industries LP is authorized to change this limited warranty in any way or grant any other warranty unless such change is made in writing and signed by the Degelman Service Manager.

This limited warranty is subject to any future availability of supply, which may directly affect Degelman's ability to obtain materials or manufacture replacement parts.

Degelman reserves the right to make improvements in design or changes in specifications at any time, without incurring obligations to owners of equipment previously delivered.

This limited warranty is subject to compliance by the customer to the enclosed *Retail Customer's Responsibility Under Degelman Warranty*.

Warranty

Retail Customer's Responsibility Under Degelman Warranty.

It is the retail customer and/or Operator's responsibility to read the Operator's Manual, to operate, lubricate, maintain and store the equipment in accordance with all instructions and safety procedures. Failure of the operator to read the operators manual is a misuse of this equipment.

It is the retail customer and/or operators responsibility to inspect the product and to have any part(s) repaired or replaced when continued operation would cause damage or excessive wear to other parts or cause safety hazard.

It is the retail customer's responsibility to deliver the product to the authorized Degelman dealer, from whom he purchased it, for service or replacement of defective parts, which are covered by warranty. Repairs to be submitted for warranty consideration must be made within forty-five days of failure.

It is the Retail Customer's responsibility for any cost incurred by the dealer for hauling of the product for the purpose of performing a warranty obligation or inspection.

WARRANTY INFORMATION

Make certain the warranty registration card has been forwarded to:

**Degelman Industries LP
Box 830 -272 Industrial Dr.
Regina, SK, Canada
S4P 3B1**


Always give your dealer the serial number of your Degelman product when ordering parts or requesting service or other information.

The serial number is located on the machine as shown in the diagram below. In the space provided record the model number, the serial number and the date of purchase to assist your dealer in providing you with prompt and efficient service.

SERIAL NUMBER: _____

MODEL NUMBER: _____

DATE OF PURCHASE: _____



Serial Number
Plate Location